













Machine	Explode	Code	Description
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	1		Lid Handle
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	2		S/S Lid
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	3		Body Handle
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	4		S/S Reservoir
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	5	AF336	Tap
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	6	AK109	Thermal Cut out
GL346 - Buffalo Manual Fill Water Boiler 10Ltr			Manual-Reset Assembly
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	7		Steel Support Bracket
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	8		S/S Base
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	9		Bottom Cover
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	10		Plastic Foot
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	11	AK110	Temperature Dial
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	12	AK818	105C Thermostat
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	13		Red Control Light
GL346 - Buffalo Manual Fill Water Boiler 10Ltr			Green Control Light
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	14		Power Cord&Plug
GL346 - Buffalo Manual Fill Water Boiler 10Ltr	15		Power Cord Clip