




Machine	Explode	Code	Description
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	1		Lid Handle
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	2		S/S Lid
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	3		Body Handle
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	4		S/S Reservoir
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	5	AF336	Tap
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	6		Thermal Cut out
GL347 - Buffalo Manual Fill Water Boiler 20Ltr			Manual-Reset Assembly
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	7		Steel Support Bracket
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	8		S/S Base
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	9		Bottom Cover
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	10		Plastic Foot
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	11	AK110	Temperature Dial
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	12	AK818	105C Thermostat
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	13		Red Control Light
GL347 - Buffalo Manual Fill Water Boiler 20Ltr			Green Control Light
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	14		Power Cord&Plug
GL347 - Buffalo Manual Fill Water Boiler 20Ltr	15		Power Cord Clip